

## Q&A

# Breaker troubleshooting

If you're having problems with your breaker, please refer to following checklist to see if the problem can be resolved. If the problem still persists, please contact the BA service team.

CAUSE	REMEDY
Pressure and return lines mixed up	Connect breaker hoses correctly
Check valve in pressure and/or return lines closed	Open check valve
Gas pressure in piston accumulator too high	Check pressure in piston accumulator, reset to correct value
Oil level in tank too low	Refill oil
Defective screw couplings blocking pressure or return line	Replace defective coupling halves
Electrical equipment for breaker hydraulics defective	Check electrical equipment for breaker hydraulics
Power Adapt Active (Shut Off Valve) HB2000 to HB10000 models	Check and reduce carrier engine speed and/or mode level



**BREAKERS &  
ATTACHMENTS**



FOLLOW US ON:    

**WWW.BAEG.COM.AU**  
sales@baeg.com.au